



YAMAHA STEERING STEM MOUNT

INSTALLATION INSTRUCTIONS:

- 1). Shut off gas supply at fuel tank
- 2). Disconnect fuel line at fuel tank
- 3). Remove body plastic over fuel tank
- 4). Remove fuel tank
- 5). Unbolt existing steering stem mount. Keep all hardware to re-use
- 6). Clean steering stem
- 7). Apply light film of grease to inside of new mounting blocks and o-rings
- 8). Slip o-rings around steering stem
- 9). Install new mounts, guiding o-rings into their grooves (*Slightly rotating the block or stem at this point will help o-rings seat*)
- 10). Re-install stock bolt sleeves, bolts, backing plate and lock tab
- 11). Tighten all bolts and bend over lock tab
- 12). Grease your new steering stem mount with any general purpose grease
- 13). Re-install the fuel tank, reconnect fuel line, and re-install plastic over fuel tank

RECOMMENDED: Grease your new steering stem mount often for maximum performance, life and less stiction!



YAMAHA
#355-51000

NOTE:
Installation process may vary by ATV model

OMI PRODUCTS
540 Danforth Street
Coopersville, MI 49404

1-800-472-2464